

Important instructions: • Read the manufacturer's instructions carefully • The product temperature and the ambient temperature must be between 15 °C and 30 °C • Ensure good ventilation at all times during application and the drying period • Do not use microfibre cloths • Do not throw the impregnated cloths or pads in the bin as they can self-ignite. Leave them to dry in the open air.

A. After installation – initial treatment (optional)

Frequency: as soon as the parquet is laid.

Product: WOCA® Hardwax Oil Swift

- This step is recommended to extend the life of the protection (factory oiling) and to make maintenance easier. The hardwax oil makes the parquet more water-repellent and is strongly advised in the bathroom.
- Vacuum to remove all dust and dirt.
- Clean the parquet with **WOCA® Intensive Cleaner** (minimum dilution – 1/40 or ½ glass in 5L of water). Rinse well and leave to dry.
- Apply the hardwax oil (**Hardwax Oil Swift**) evenly and without excess using a medium-pile roller (7-8 mm). Work with good lighting to see the uniformity of the coat.
- Leave to dry 24h (total curing time 5 to 7 days).



B. Regular cleaning

Frequency: weekly

Product: WOCA® Natural Soap

- Dilute the product in cold water at a rate of 8.5cl (2 caps) per 5L (½ bucket) or use our **Ready-mix** product.
- Whether you use a Spray Mop (see our accessories) or a scrubber, always clean in the direction of the fibres.
- Do not leave water on the surface after cleaning. Dry well (no microfibre cloths).



C. Renovation

Follow this step if you have not maintained your parquet for a long period.

Frequency: as required

Products: WOCA® Intensive Cleaner

- Dilute the product in lukewarm water at a rate of 12.5cl (½ glass) per 2.5L (¼ bucket).
- Clean the floor with a scrubbing brush, letting the product act briefly (5 minutes) to dissolve the dirt.
- Rinse with clean water using a damp cloth or mop, then with a well-wrung cloth or mop and leave to dry.
- Apply 1 or 2 coat(s) of **WOCA® master natural oil** (or coloured depending on the desired result – see next point) following WOCA®'s recommendations and leave to dry 48h.
- Influence of the Woca® master oil used on the shade:
 - Invisible oil: ≈ neutral (apply the invisible primer beforehand)
 - Master white oil: the parquet shade will lighten slightly.
 - Master natural oil: the parquet shade will darken slightly.
 - Master Brown oil: enhances the colour of the parquet (Caramel only).
- Then apply the hardwax oil **WOCA® Hardwax Swift Oil** as for the initial treatment.



D. Repair

For superficial scratches (at the level of the protective coat), if you do not wish to carry out a renovation step:

- mark off the area to be repaired with masking tape (ideally taking complete boards).
- then lightly key (with grade 1000 paper) the scratched area,
- rinse with a lightly damp cloth.
- Then continue by applying **WOCA® Hardwax Swift Oil** with the roller (step A).

For deeper scratches, it is preferable to call in a professional.